MicroStrain Quick Start Guide: 3DM-GX5-35 AHRS/GNSS

The 3DM-GX5-35 Attitude and Heading Reference System (AHRS) with Global Navitation Satellite System capability is

the smallest and lightest industrial AHRS/GNSS with an Adaptive Extended Kalman Filter available. Congratulations on your purchase.

Let's get started:



The 3DM-GX5-35 communicates through a serial connection and is monitored by a host computer. Sensor measurements and computed outputs can be viewed and recorded with SensorConnect software, available as a free download from the LORD Sensing website. Alternatively, users can write custom software with the open source data communication protocol, also available on the site. Data is time-aligned and available by either polling or continuous stream.



The sensor and connectivity kit are purchased separately. There are two variations of the kit, USB cable (p/n 6212-3004) and RS232 communications and global power (p/n 6212-3001). This guide assumes that you have a connectivity kit and will download the latest version of SensorConnect[™] software.

Step 1:

Download and install the latest SensorConnect™ software: http://updates.microstrain.com/SensorConnect 12.3.0 x64.msi



Step 2:

Unpack the sensor and connectivity kit.

Step 3:

Attach the interface cable to the sensor. If you are using the RS232 version, you must also plug the power supply into the power jack on the RS232 DB9 connector, and then plug it into AC power.

Step 4:

Plug the interface cable into the appropriate computer input. The green LED on the sensor should first blink, then pulse slowly to indicate it is in the idle mode. Sensors are factoryset to idle mode.

Step 5:

Start SensorConnect. The first thing you must do is create a repository file to which you will store settings and data. Click 'home' to bring up this screen:

		۵	Oata Repositories 🛛			
Active	Data Repo	‡↓	Created 🗍	Last Used 👔		
~	Your Test		2019/12/12 10:01:13 AM	2019/12/12 10:01:13 AM	5	
				🖬 Import Repo	Create N	New Re

Step 6:

If you are using a USB interface, the sensor will initiate communications with SensorConnect automatically. This is indicated by a green dot just right of the sensor name. You will also notice that the green LED on the sensor is blinking rapidly, indicating active communications. Click on 'devices' to see this on screen:

Home	Devices	Data						
 local 								
3DM-G	(5-25 75662							
3DM-G	3DM-GX5-35 67451							

Step 7:

If you are using RS232, click on Devices, and '+ Add Device'.


USI	B devices are autom	natically discove	red when plugge	d in.	
	To add a TCP/IP or	Serial device, us	e the form belov	v.	
	Connection:	TCP/IP		•	
Found 1	vetwork Devices		IP Address:		
Name	IP Address	Port	Port:	5000	
V02000000090353	10.6.11.95	5000	Porc	3000	
		Add Device			

Select serial, and identify your serial port. Clicking the port select arrow should identify available comm's ports. Sensors are factory set to 115200 baud. Click Add Device, and Done:

	matically discovered w or Serial device, use the	
v	Serial	Connection:
Ŧ	COM15	Port:
v	115200	Baud Rate:
	Add Device	

Step 8:

Close that window, and click on your device to see settings:



Step 9:

Click on sampling, + add channel field, and Attitude (Euler RPY). Set data rate to 10Hz or higher. Then click "apply" and "start"


IMU			
Time	Field: 🔽 GPS Correlation Timestamp	10Hz 💌	
×	Channel Field	Data Rate 10Hz 💌	
×	Attitude (Euler RPY)	10Hz	*
+ Ad	d Channel Field		Ŧ

Step 10: Click on Data, and +Add Widget.


	0	-		
<u>_</u> 0.	Sen	sorC	onn	lect
		A 10 1 10	w111	The late is

Home	Devices	Data	
Char	nnels Set	tings	+ Add Widget

Step 11: Click on 3D Model.



Step 12: Your screen will look like this:




Step 13:

Now let's get data into the model. Under Channels, click on local data, and click on your device. There will be a green dot alongside the sensor name, indicating that it's connected.



Clicking on your sensor will bring up a selection of data channels. Click on Roll, Pitch and Yaw:



Step 14:


Test the linkage to the widget aircraft...pick up the sensor, and move it in 3 axes. The plane should respond.

Now you know that your sensor is working, and you're in command. Let's add some other widgets. Click on + Add Widget, and select Linear Gauge. Click on the Gauge icon, and select the Roll data channel, in the local data list:



The X icon will close this gauge. The page icon to its left will make duplicates.

Click on the duplicate icon twice, and place two more linear gauges. Click on each of them, and select pitch and yaw data. You'll see the gauge displays move, as you manipulate the sensor.



MicroStrain Quick Start Guide: 3DM-GX5-35 AHRS/GNSS

Step 15:

There is one last step to consider, before exploring SensorConnect further, or in corporating the sensor into your own data handling system.

Click on Devices, and select Monitor Bytes. You can see streaming data:

	SDIVI	I-GX	5-35	6745	i1 by	te m	onit	oring	9			-	_		\sim
зD	M-0	GX	5-3!	5 67	745	1 b	yte	mc	nit	oriı	ng				
ecc	ord t	to fi	le:							P	⇒				
62															
Rea	d - 2	2019	-12-	20 2	0:11	:24.4	4194	409	6						
Rea	d - 2	2019	-12-	20 2	0:11	:24.4	4198	377	6						
65	80	10	OE	oc	3B	AA	B5	C6	3B	EO	84	9D	40	10	64
E1	OE	12	40	9F	В2	09	37	4B	C6	AS	00	00	00	06	7D
ΕO															
Rea	d - 2	2019	-12-	20 2	0:11	:24.4	4313	744	0						
75															
Rea	d - 2	2019	-12-	20 2	0:11	:24.4	4315	408	0						
65	80	10	OE	oc	3B	AA	C5	FC	зB	EO	93	в4	40	10	64
AC	OE	12	40	9F	В2	13	74	BC	6A	7 F	00	00	00	06	E7
64															
Rea	d - 2	2019	-12-	20 2	0:11	:24.4	4369	986	56						
75															
Rea	d - 2	2019	-12-	20 2	0:11	:24.4	4371	580	8						
65	80	1C	OE	oc	зв	AB	зB	25	зB	ΕO	A6	68	40	1C	64
C8	OE	12	40	9 F	В2	1D	В2	2D	OE	56	00	00	00	06	9E

Pin to Bottom

Clear

Step 16:

When you're done exploring SensorConnect, click on Home, and select a data repository to save your setup and data.

	C	Oata Repositories 🛛		
Active	Data Repo 🌐	Created 🗍	Last Used	L .
	TEST	2019/12/20 10:31:06 AM	2019/12/20 10:31:06 AM	b
			🖬 Import Repo	Create New Repo

Now, you're ready to put your sensor to work in your application. For sensor pinout and other details, refer to the user manual, which is found on the MicroStrain website:

https://www.microstrain.com/inertial/3dm-cx5-45

Additional information about MicroStrain data communications software and related information will be found by scrolling down to DOCUMENTATION.

Details about other MicroStrain software can be found here: <u>https://www.microstrain.com/software#web</u>

LORD Sensing MicroStrain

459 Hurricane Lane Suite 102 Williston, VT 05495 • USA www.microstrain.com Customer Support Center (in United States & Canada) Tel: +1.802.862.6629 Email: sensing_sales@LORD.com | sensing_support@LORD.com For a listing of our worldwide locations, visit LORD.com



©2019 LORD Corporation Document 8501-0047 Rev -. Subject to change without notice.